



ReadySHARE Cloud Mac OS Agent Utility User Guide

Step 1: After downloading the installation package from the <http://www.netgear.com/readyspace> page, run it and follow the instructions to install it.


Step 2: Select **Go > Applications > ReadySHARE Cloud**.




Step 3: From the Mac OS task bar, click the ReadySHARE Cloud icon and select **"Properties"**.




Step 4: In the **Properties** page, enter your ReadySHARE Cloud User ID and Password, and click **OK** to log in.



Step 5: Once you have logged in, click the ReadySHARE Cloud icon in the task bar and select “**Connect to ReadySHARE...**”.



Step 6: The ReadySHARE Cloud Shares window will show up, and your router with ReadySHARE Cloud enabled should show up. Double click on the entry to connect. When asked to enter your name and password for the server “5.x.x.x”, enter the router user name “**admin**” and the router password (default is “**password**”), then click **Connect**.



Now you have access to your ReadySHARE USB storage remotely:

